


TM

disklok



IMPORTANT

User Information

USER INFORMATION

Guidelines

This information leaflet contains all you need to know about your new Disklok. We strongly recommend that you read the fitting instructions before you try the Disklok on your vehicle.

The following guidelines are aimed to assist you in fitting your Disklok correctly, however, we feel that after a short period you will become quite proficient in fitting the Disklok. The guidelines assume the vehicle is parked and the ignition key has been removed, thus engaging the vehicles own steering lock prior to fitting your Disklok.

Leather Steering Wheels

The Disklok may leave lay lines or marks when removed.



**Risk of trapping hand / finger
when fitting and removing.**

Fitting

1. Open the Disklok by pulling apart the two halves at the top.
2. Unfold the locking handle from the carrying position.
3. The Disklok is now ready to fit, place the open Disklok over the steering wheel avoiding at all times contact with the windscreen and then bring the two halves together again.
4. Bring the locking arm over into the locking position, with the handle in place push home the locking bar in the direction indicated on the handle.
5. Holding the locking bar in the closed position press home the lock on top of the handle. Your Disklok is now protecting your vehicle.

Removal

1. Using the security key to open the lock, the locking bar is released.
2. With the locking bar released, lift the handle over to the opposite side of the disk avoiding at all times contact with the windscreen, pull apart the two halves of the disk and remove from the steering wheel.
3. Whilst the Disklok is in the open position, fold away the handle into the carrying position, then close the two halves together again.

IMPORTANT

Unique Feature

Having fitted your Disklok, it will appear to be loose on the steering wheel and this may cause some concern. There is no need to worry, the Disklok's unique design allows it to spin on the steering wheel, therefore, it cannot be used to force the vehicles own steering lock.

IF THE KEY DOES NOT OPERATE THE LOCK CORRECTLY

When the lock is working correctly the key will rotate three quarters of a turn, however, if the key only rotates one quarter of a turn the indications are that a disc in the lock mechanism is out of line. This is not a fault with the lock but a feature of this type of high security lock, to remedy this please read the following.

The security lock incorporated in the Disklok utilises a multidisc mechanism, on occasions these discs can rotate out of alignment causing a resistance to entering the key fully into the lock, preventing it from opening. To align the discs, insert the key and turn it from side to side with a slight downward pressure, the discs will move back into position and the key will operate the lock correctly.

DO NOT FORCE THE KEY

For further advice and also lock maintenance call the Helpline, (01257) 795100.

UNDER NO CIRCUMSTANCES OIL THE LOCK

Unable to remove the Disklok

If you are unable to remove your Disklok because you have lost your key or someone has damaged it whilst attempting to remove it, you should call the Disklok Helpline, (01257) 795100, for assistance.

DISKLOK U.K. strongly recommend that you keep a record of your key code in a safe place

For more information, call (01257) 795100

USER INFORMATION

Key Security

Key security is of the utmost importance, therefore, Disklok recommend that you take note of the following:

- a. Ensure that all keys operate the lock correctly
- b. Remove the key tab with the computerised security key code from the key ring and put it in a safe and secure place.
- c. The keys should then be removed from the key ring and kept separate at all times.
- d. Should you lose or misplace your key(s), replacements can be sought if you have the computerised security code.

Replacement Keys

Additional or replacement keys can only be purchased from Disklok U.K. For further details call the Helpline (01257) 795100.

Hot Weather Warning

In hot sunny weather, if your vehicle is parked for any length of time in direct sunlight the Disklok may get quite hot. It is advisable to put a sun shield or blind in the front windscreen, this will help reduce the problem.

Locking Pin

The tab at the end of the locking pin may work loose, in the event of this happening the retaining screw at the end of the locking pin should be retightened. Do not over tighten the screw.

Storage

The Disklok when not in use should be stored in the boot.

Product Guarantee

This Disklok is guaranteed for 36 months against mechanical failure from date of purchase. In the unlikely event of a fault occurring with your Disklok contact the Helpline on (01257) 795100. This guarantee is only valid if the product has been used as directed and proof of purchase is provided.

This guarantee does not affect your statutory rights.

Disklok U.K. reserve the right to change or alter the specification of the Disklok at any time, in order to maintain attack testing criteria.

**WE RECOMMEND MEASURING
YOUR STEERING WHEEL**


CAR

TYPICAL SIZE:
SMALL DISKLOK / 35 - 39 CM



4x4

TYPICAL SIZE:
SMALL DISKLOK / 35 - 39 CM
MEDIUM DISKLOK / 39 - 41.5 CM
LARGE DISKLOK / 41.5 - 44 CM



VAN

TYPICAL SIZE:
SMALL DISKLOK / 35 - 39 CM
MEDIUM DISKLOK / 39 - 41.5 CM
LARGE DISKLOK / 41.5 - 44 CM



MOTOR HOME

TYPICAL SIZE:
SMALL DISKLOK / 35 - 39 CM
LARGE DISKLOK / 41.5 - 44 CM



disklok

Disklok House Preston Road, Chorley
Lancashire, PR7 5HH, UK

Tel: (01257) 795100 Fax: (01257) 795101

disklok™

HELPLINE

01257 795100



1996, 2000, 2003, 2005



2001, 2002, 2003, 2004

A Real 'Hard Case' to Beat