



User Manual

Operation Guide



1. Dig out the fan body according to the diagram with your finger.

2. It is hand-held fan when the front cover opens to 180 degree.

PowerKey

Short press this button, the fan goes from one-two-off-on two speed circularly.

Indicator Light

Charging status:
white light flashing

Full state:

white light is always on

Working status:


green light flashes slowly

Charge digital devices such as mobile phones

Status:
White light is always on

USB Output

MicroUSB Input



3.It is a desk fan that can be placed on the desktop when the front cover opens to 270° degree.

Note

1. Do not touch the rotating fan blade with hands. For users with long hair, please keep a distance to prevent the hair involvde.
2. When the product is not in use, please make the fan body and front cover is together to avoid damage.
3. Please make the two blades overlapped before putting the front cover back.



Warning

- 1.This product uses lithium-ion battery (no memory funvtoin). It is okay to use while charging. Recharging it only battery is in low power is not a good idea. To keep the battery life, please keep the battery charged more times.
2. When external obstacles touches the spinning blade, it will stop rotation immediately. Please press the power button to restart this fan after obstacles are removed.
3. This fan is not a children' s toy. Kids under 10 years old must be supervised to use this item to avoid danger.
4. If the ambient temperature of the battery exceeds 60 Celsius degree or the battery is extruded and dissected, the battery is extruded and dissected , the battery life will be shortened greatly. What' s worse, there comes the risk of leakage or explosion.

※ When the battery is low energy, the 1 speed might be turned on while the 2 speed is not.

※ This unit has current detection function. When external obstacles (like fingers) touch the spinning blade, it will stop operation immediately for safety. Remove obstacles and restart the fan.

Warranty

1. Please keep the warranty card as the mainenance certificate.
2. One year warranty starts from the date of purchase.
3. If this product is used normally under warranty while the fan' s material or function has a problem or shop working, we will offer free repair or replacement.

The Following Conditions Will Not Be Free Maintenance

The company offers limited warranty for the products within the warranty period.

We offer limited warranty yet the below conditions will not get a free warranty although within one year from the purchase of date.

1. Your fan exceeds the warranty period.
2. Equipment failure or damage caused by abnormal use. like incorrevt installation, wrong maintenance without following the user manual we offered.

3. The damage vaused by the dismantle movement of a non-our-company authorized maintainer.
4. The breakdown and damage vaused by the accidental factors or human operation (including incorrect operation, move, scratch and bump, the inappropriate voltage and current etc.
5. The brakdown and damage caused by the force majeure (like earthquake, fire).

Packing Accessories

※ Fan *1 ※ Use Manual*1 ※ MicroUSB Charging Cable *1

Product Parameter

Product Name: folding fan

Product Model: FS08

Battery Capacity: 7.2Wh/3.7V

Rated Capacity: 6.12Wh/TYP 5V/0.5A

Charging Time: 2-3小时

Input: 5.0V/1.0A[TYP]

Output: 5.0V/1.0A[TYP]

Product Weight: 115g

Product Size: 113.5 x 35.8 x 37.4 mm

