


PELONIS

OWNER'S MANUAL

TOWER FAN MODEL: FZ10-17K



READ AND SAVE THESE INSTRUCTIONS

CAUTION

Read Rules for Safe Operation and Instructions Carefully.

WARNING


1. If the supply cord is damaged, it must be replaced by manufacturer or its service agent or a similarly qualified person in order to avoid a hazard.
2. To protect against the risk of electrical shock, do not immerse the unit, cord or plug in water or other liquid.
3. This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
4. When the appliance is not in use and before cleaning, unplug the appliance from the outlet.
5. Keep electrical appliances out of reach from Children or infirm persons. Do not let them use the appliances without supervision.
6. When the fan was assembled, the rotor blade guard shall not be taken off anymore
 - Prior cleaning unplug the fan.
 - The rotor guard shall not be disassembled/opened to clean the rotor blades.
 - Wipe the fan enclosure and rotor blade guard with a slightly damp cloth.

RULES FOR SAFE OPERATION

1. Never insert fingers, pencils, or any other object through the grille when fan is running.
2. Disconnect fan when moving from one location to another.
3. Be sure fan is on a stable surface when operating to avoid overturning.
4. DO NOT use fan in window, rain may create electrical hazard.
5. Household use only.

INSTALLATION INSTRUCTIONS

■ Name of components



Base Installation


- Take out the fan body and the spare parts from the box. Put the front base onto rear base and join them together. Pass the power cord through the flute, then insert the fan body into the base.

Flute

- Fix the fan body on the base with the plastic nut.

Note: All the pictures in this manual are for explanation purpose only. Any discrepancy between the real object and the illustration in the drawing shall be subject to the real subject.

INSTRUCTIONS FOR USE



Warning: Do not rotate the timer counter-clockwise to "ON" from "120min".

MAINTENANCE INSTRUCTION

The fan requires little maintenance. Do not try to fix it by yourself. Refer it to qualified service personnel if service is needed.

1. Before cleaning and assembling, fan must be unplugged.
2. To ensure adequate air circulation to the motor, keep vents at the rear of the motor free of dust. Do not disassemble the fan to remove dust.
3. Please wipe the exterior parts with a soft cloth soaking a mild detergent.
4. Do not use any abrasive detergent or solvents to avoid scratching the surface. Do not use any of the following as a cleaner: gasoline, thinner, bending.
5. Do not allow water or any other liquid into the motor housing or interior parts.

CLEANING

1. Be sure to unplug from the electrical supply source before cleaning.
2. Plastic parts should be cleaned with a soft cloth moisten with mild soap. Thoroughly remove soap film with dry cloth.

DISPOSAL: Do not dispose of electrical appliances as unsorted municipal waste, use separate collection facilities. Contact your local government for information regarding the collection systems available. If electrical appliances are disposed of in landfills or dumps, hazardous substances can leak into the groundwater and get into the food chain, damaging your health and well-being.



| Description | Symbol | Value | Unit |
|--|--|-------|--------------------------|
| Maximum fan flow rate | F | 28.17 | m ³ /min |
| Fan power input | P | 29.6 | W |
| Service value | S_v | 0.95 | (m ³ /min)/ W |
| Standby power consumption | P_{SB} | - | W |
| Off power consumption | P_{OFF} | 0 | W |
| Fan sound power level | L_{WA} | 60.2 | dB(A) |
| Maximum air velocity | C | 3.09 | meters/sec |
| Seasonal electricity consumption | Q | 9.472 | kWh/a |
| Measurement standard for service value | GB/T 13380-2007 | | |
| Contact details for obtaining more information | Homebrand-spares.co.uk PO Box 1597, Northampton, NN2 1GW www.pelonis.com | | |

PRODUCT GUARANTEE

This product comes with a 1 year guarantee from the original date of purchase. If any defect arises due to faulty materials or workmanship, the faulty products must be returned to the place of purchase. Refund or replacement is at the discretion of the retailer. This guarantee is in addition to and in no way prejudices your statutory rights.

The Following Conditions Apply:

- ◆ The product must be returned to the retailer with proof of purchase or a receipt within the 1st year of purchase.
- ◆ The product must be installed and used in accordance with the instructions contained in this instruction guide.
- ◆ It must be used only for domestic purposes.
- ◆ It does not cover wear and tear, damage, misuse or consumable parts.
- ◆ This guarantee is valid in the UK and Republic of Ireland.

For all customer service enquires please contact us below:

Homebrand-spares.co.uk
PO Box 1597, Northampton
NN2 1GW

Email: info@homebrand-spares.co.uk
Tel 01733 88 99 48