

# www.ChristmasTreeWorld.co.uk

We are very pleased that you have chosen a 180cm / 6ft Ultra Devonshire Fir Tree from www.ChristmasTreeWorld.co.uk and we are sure it will give you years of pleasure.

However in the unlikely event of a part failing, contact us immediately and we will arrange to replace the part providing it is within the statutory warranty period.

Please read the following carefully before first use to ensure safe and satisfactory use of this product.

## Warning

This tree is suitable for indoor display only, the transformers must remain indoors at all times. The tree should always be positioned on a flat rigid surface.

- Do not operate this product whilst in packaging.
- Disconnect from the mains supply when not in use.
- Do not connect this product electrically to another product.
- Do not operate in confined space or allow it to come into contact with any flammable materials.
- Do not allow any parts of this set to come into contact with direct heat or flame.
- A transformer is a sealed unit, do not attempt to open or tamper.
- There are no user replaceable parts in this set.
- The flexible supply cable is not user replaceable.
- Please keep a free flow of air around the transformer.

## The Environment


Do not put lights in regular domestic waste at end of life. For further advice on disposal of electrical goods contact your local authority, the packaging is widely recyclable.

## Assembly Instructions -

The tree comes in 3 sections and will sit on a secure metal stand.

### Assembling the tree stand

- Pull apart the legs of the stand so they are into an x-shape, then place the stand on a level surface.
- When inserting the bottom section of the tree into the assembled stand, insert and turn the eyebolts into the stand and tighten until the tree pole is firmly secured.




STEP 1. Remove the protective caps (if present) from the tree bottom, and insert the pole into the tree stand or Pot.

STEP2. Work branch by branch, row by row from the bottom up, gently fanning out all of the branch tips to resemble a peacocks tale.

STEP3. Shape the branches to your preference by working from the bottom to the top, When adjusting branches, ensure that all the wires are free of the branch hinge.

For more information please please don't hesitate to contact us.



## 180cm / 6ft Ultra Devonshire Fir Tree Specification

Item No: TR-UDEV-WW-WH-180

Product description: WW/WH Colour Change

Lights Transformer: JT-DC31V3.6W-E3

Input: 220-240V~ 50-60Hz


Output: 31V - 3.6W

## Pre-Assembly - What's in the box.

PART	DESCRIPTION	QUANTITY
TR-UDEV-WW-WH-180-1	Top Section	x1
TR-UDEV-WW-WH-180-2	Middle Section	x1
TR-UDEV-WW-WH-180-3	Bottom Section	x1
TR-UDEV-WW-WH-180-4	Tree Stand	x1
JT-DC31V3.6W-E3	Transformer	x1

### OR Assembling the tree pot / Plastic feet

- Place the pot on a level surface.
- Attach the plastic feet by placing them into the grooves located on the bottom section of the tree pole.




STEP4. Upon finishing each section, ensure that you have tweaked every branch before inserting the next section and repeating the process. Once finished make small adjustments to fill any gaps.

STEP5. Insert the lighting chain connections together, then plug into a power outlet. All your lights should now be lit.



Please retain for future reference  
Linten Garden Products LTD



PART	DESCRIPTION	QUANTITY
TR-UDEV-WW-WH-180-1	Top Section	x1
TR-UDEV-WW-WH-180-2	Middle Section	x1
TR-UDEV-WW-WH-180-3	Bottom Section	x1
TR-UDEV-WW-WH-180-4	Tree Stand	x1
JT-DC31V3.6W-E3	Transformer	x1

Transformer JT-DC31V3.6W-E3

## SHAPING INSTRUCTIONS

Shaping the branches of your tree is the last step of assembly before adding your decorations. The more care and attention you give to this process will result in a more aesthetically pleasing final outcome.

- Upon opening the box you will find each branch is shipped from the factory with the tips compressed to the centre.
- Each branch tip must be shaped to its proper position to give the tree a natural look. This is achieved by gently grasping the left and right tips and spreading them out away from the centre of the tip.
- Tips should then be bent slightly upward to add a more natural looking appearance.

## STORAGE TIPS

Christmas Tree World recommends all of the tree sections are stored properly, and kept out of the way, in a cool, dry place to prevent damage.

- Remove all decorations from your tree.
- Compress each tree section so that it will fit more easily into your storage unit.
- Store your tree in a cool, dry location to prevent it from acquiring a musty odour while in storage.

Official Christmas Tree World storage bags can be purchased from our website

## USE & CARE INSTRUCTIONS

- Before using or reusing, inspect the product carefully. Discard any products that have cut, damaged or frayed wire insulation or cords, loose connections, or exposed copper wire.
- Always unplug the product when cleaning.
- Always unplug the product if you choose to move or reposition.

*Thank you for choosing  
Christmas Tree World*