


Door/Window Sensor

User Manual



*Please read this manual carefully before use
and keep it for future reference.

Specification:

Battery:	AAA 1.5V x 2 , not included
Magnetic control distance:	≥15mm
Low power undervoltage:	≤2.4V
Alarm mode:	APP notification push (Smart Life / Tuya Smart)
Wireless Type:	WiFi / ZigBee
Size: Main body:	70*24*19mm
Permanent magnet:	43*10*14mm

Feature:


- Contact Alarm
- Low battery alarm
- Alexa/Google compatible
- OTA firmware upgrade supported

How to use:

1. Push the mounting bracket upward and take out the bracket, then insert the battery.



2. Put the battery into the battery bin and place it according to the graphics in the battery bin. After two batteries are loaded the indicator lights are always on and then off.



3. Download Smart life APP in app store or google play store, or scan the following QR code.



iOS/Android


WIFI CONTACT SENSOR CONNECTION:

4. Register with email , click " My Home " interface "
+ " or click " Add Devices " in the middle blank.

Select the security sensor and click on the
Contact-sensor (WIFI)



5. With the card pick-up pin in the accessory package, hold the reset key for more than 5 seconds, and the indicator flashes into the automatic network connection mode. Enter the WiFi password according to the prompt, and click to confirm.



6. In the hotspot network connection Mode, the indicator flashes quickly, holds the reset key for 5 seconds with the card pickup pin, the indicator flashes slowly, and enters the manual network connection mode. APP chooses compatible mode. According to the prompt, enter "WiFi password" and click confirmation, then switch to the WiFi settings interface. Connect Smartlife-XXXX network and return to APP to continue adding devices.



7. Bluetooth mode, after entering the fast flashing state, turn on the Bluetooth of the mobile phone, enter, Then will see "Devices to be added" on mobile app. Finally press "Go to add", it will connect the Wi-Fi network automatically.


8. Network connection successfully, click on the door magnetic icon to enter the interface open the door magnetic, APP will remind you the door is open, close the magnet door magnetic APP will remind you the door is closed.

Zigbee Contact sensor connection

Notice:

This device only can work when along with a Zigbee Gateway. You need to connect wifi with a zigbee gateway successfully before use such zigbee contact sensor.

9. Click "Add subdevice" in App of gateway homepage. then long press reset key of Zigbee door detector by a pin until led light blinked , click " LED already blink " to connect door detector with gateway .



10.It will be showed an icon of Zigbee door detector in APP when connection successful.

