

Owner's Manual



Enjoy it.

650W Oil Filled Radiator

This product is only suitable for well insulated spaces or occasional use.

IMPORTANT:

PLEASE READ ALL OF THE INSTRUCTIONS CAREFULLY AND RETAIN FOR FUTURE REFERENCE.

IMPORTANT SAFETY INSTRUCTIONS

- When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock and injury to persons.
 - Check the voltage indicated on the rating plate corresponds with that of the local network before connecting the appliance to the mains power supply.
- CAUTION:** Some parts of this appliance can become very hot and can cause burns. Particular attention has to be given where children and vulnerable people are present.
- Children younger than 3 years old should be kept away from the appliance unless continuously supervised.
 - Children aged from 3 years and less than 8 years should only switch on/off the appliance, provided that it has been placed or installed in its intended operating position and they have been given supervision or instruction concerning the use of the appliance in a safe way and understand the hazards involved.
 - Children aged from 3 years and less than 8 years shall not plug in, regulate and clean the appliance or perform user maintenance.
 - This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
 - Children should be supervised to ensure they do not play with the appliance.
 - This appliance is not a toy.
 - Children should not carry out cleaning or user maintenance without supervision.
 - This appliance contains no user serviceable parts. If the power supply cord, plug or any part of the appliance is malfunctioning or if it has been dropped or damaged, only a qualified electrician should carry out repairs. Improper repairs may place the user at risk of harm.
 - Keep the appliance and its power supply cord out of the reach of children.
 - Keep the appliance and its power supply cord away from heat or sharp edges that could cause damage.
 - Keep the power supply cord away from any parts of the appliance that may become hot during use.
 - Keep the appliance away from other heat emitting products.
 - Keep furniture, curtains and other flammable material at least one metre away from the appliance.
 - Do not run the supply cord under carpets, rugs etc. or anywhere where it may present a trip hazard.
 - Do not immerse the appliance or plug in water or any other liquid.
 - Do not operate the appliance with wet hands.
 - Do not use this appliance in the immediate surroundings of a bath, a shower or a swimming pool.
 - This appliance must not be located immediately below a socket-outlet.
 - Always unplug the appliance when not in use.
 - Do not leave the appliance unattended whilst connected to the mains power supply or when in use.
 - Do not remove from the mains power supply by pulling on the cord; switch off and remove by the plug.
 - Do not use this appliance for extended periods of time.
 - Do not use this appliance for anything other than its intended use.
 - For indoor use only.
 - This appliance is intended for domestic use only. It should not be used for commercial purposes.
 - Do not block any air intake of the appliance; place in an open, well ventilated space.
 - Do not attempt to move the appliance while it is in use.
 - Do not put objects into any openings.
 - Do not use the appliance with a programmer, timer, separate remote-control system or any other device that will switch the product on automatically, as there is a risk of fire if the heater is covered or positioned incorrectly.

- This appliance should be used on a stable, heat-resistant surface.
- Always unplug the appliance after use and before any cleaning or maintenance.
- Use of an extension cord with the product is not recommended.
- Never use accessories that are not recommended or supplied by the manufacturer. It could cause danger to the user and damage the appliance.
- On first use of this appliance there may be a peculiar smell – this will disappear after approximately 5 minutes.
- This heater is filled with a precise quantity of special oil. Repairs requiring opening of the oil container are only to be made by the manufacturer or his service agent who should be contacted if there is a leak.
- When disposing of the appliance, follow the regulations concerning the disposal of oil.



HOT SURFACE: Do not touch the hot section or heating components of the appliance.



WARNING: In order to avoid overheating, do not cover the appliance.



ASSEMBLY INSTRUCTIONS

Unpack the radiator from the box and remove any packaging and place any packaging inside the box for storage or disposal. Check the radiator is undamaged.

Install the plastic feet on the base of the radiator - turn the radiator upside down and slide the feet into place.

Position the radiator on a flat, stable, heat-resistant surface (ensuring it is always placed the correct way up), at least one metre away from furniture, curtains or any other flammable materials.


(See also diagram to the right).



Parts

1. Handle
2. Thermostat Dial
3. On/Off Switch
4. Oil Filled Fins
5. Front and Rear Plastic Feet

OPERATING INSTRUCTIONS



NOTE : When the radiator is turned on for the first time or after having not been used for a long period, it may emit some smell and fumes. These will disappear when the radiator has been on a short while.

- 1) Choose a suitable location for the radiator, taking into account the safety instructions above.
- 2) Insert the plug of the radiator into a suitable socket.
- 3) Turn the thermostat dial fully in a clockwise direction to the maximum setting.
- 4) Press the On/Off switch to ON position. When the heating element is on the switch will illuminate.
- 5) When the desired room temperature has been reached, the thermostat dial should be turned slowly anti-clockwise until the thermostat is heard to click off and the light on the power switch is seen to go out. After this the radiator will keep the air temperature in the room at the set temperature by switching on and off automatically.

OVERHEAT PROTECTION

This heater includes an overheat protection system that shuts the unit off if it overheats due to abnormal conditions. If this occurs turn the heater "OFF", unplug it, and inspect and remove any objects on or adjacent to the heater. Allow it to cool for a few minutes, plug it back in, and resume normal operation.

CARE AND MAINTENANCE

Always unplug the radiator from the mains power supply and allow it to cool sufficiently before performing any cleaning or maintenance. Wipe the exterior of the radiator with a soft, damp cloth and allow to dry thoroughly. Do not use harsh or abrasive cleaning solvents or scourers, as these may damage the finish of the radiator. Check regularly for any blockages on the vent, to prevent the thermal cut-out device from operating. Do not immerse the radiator in water or any other liquid.

ELECTRICAL INFORMATION

(Fixed Mains Plug Only)

The mains lead supplied with this product is fitted with a BS1363/A 5 amp plug. If it is not suitable for your supply sockets it must be replaced with an appropriate plug.

If the plug becomes damaged and/or needs to be replaced please follow the wiring instructions on the next page. The plug removed must be disposed of immediately. It must not be plugged into a supply socket as this will be an electrical hazard.

If the fuse needs to be replaced it must be of the same rating and ASTA approved to BS1362. If the plug is changed, a fuse of the appropriate rating must be fitted in the plug, adapter or at the distribution board.

If the fuse in a moulded plug is replaced, the fuse cover must be refitted before the application can be used.

WIRING INSTRUCTIONS

The supply cable will be either 2-core or 3-core. Follow the appropriate wiring instructions shown. In both cases ensure that the outer sheath of the cable is held firmly in place by the cable clamp.

ELECTRICAL INFORMATION

(Power adapters only)

Never open the power adapter, you risk getting an electric shock.

Only use the power adapter that is supplied with your product.

You must always connect the power adapter to the product before connecting to the mains power supply.

The power adapter must be used indoors only, and must not be subjected to damp conditions.

The power adapter does not have any user serviceable parts.

2-CORE PLUG




WARNING: Do not connect either wire to the earth terminal.


This symbol indicates that this 2-core appliance is Class II and does not require an earth connection.

The wire coloured blue must be connected to the terminal marked with the letter N or coloured black.

The wire coloured brown must be connected to the terminal marked with the letter L or coloured red.



Live
(Brown)



Neutral
(Blue)

3-CORE PLUG



WARNING: This appliance must be earthed.


The wire coloured green and yellow must be connected to the terminal marked with the letter E, or by the earth symbol, or coloured green or green and yellow.

The wire coloured blue must be connected to the terminal marked with the letter N or coloured black.

The wire coloured brown must be connected to the terminal marked with the letter L or coloured red.



Earth
(Green &
Yellow)



Neutral
(Blue)

Live
(Brown)

TECHNICAL SPECIFICATION

Model Number:	359771
Voltage:	220-240V~ 50Hz
Total heat power:	650 W

This appliance complies with the below listed UK Directives

Electromagnetic Compatibility Regulations 2016

Electrical equipment (Safety) Regulations 2016

Ecodesign for Energy-Related Products Regulations 2010

The Restriction of the Use of Certain Hazardous Substances in Electrical and Electronic Equipment Regulations 2012

The complete declaration of conformity is available upon request for relevant enquiries

CUSTOMER SUPPORT

For all product support, please email:
customerservices@bmstores.co.uk

GUARANTEE

We hope you enjoy your product for many years.

This product is guaranteed for 12 months from the date of purchase. If any defect arises due to faulty materials or workmanship, the faulty product must be returned to the place of purchase. Refund or replacement is at the discretion of the retailer.

- The following conditions apply:
- The product must be returned to the retailer with proof of purchase or receipt.
- The product must be installed and used in accordance with the instructions contained within the instruction manual.
- The product must be used solely for domestic purposes.
- This guarantee does not cover wear and tear, damage, misuse or consumable parts.
- The guarantee will be rendered invalid if the product is re-sold or has been damaged by inexpert repair.
- The manufacturer disclaims any liability for incidental or consequential damages
- The guarantee is in addition to, and does not diminish, your statutory or legal rights.

ERP Table

Item	Symbol	Value	Unit	Item	Unit
Heat Output				Type of heat input for electric storage local space heaters only (select one)	
Nominal heat output	P_{nom}	0.3492	kW	Manual heat charge control, with integrated thermostat	NA
Minimum heat output (indicative)	P_{mim}	0	kW	Manual heat charge control with room and/or outdoor temperature feedback	NA
Maximum continuous heat output	$P_{max,c}$	0.3492	kW	Electronic heat charge control with room and/or outdoor temperature feedback	NA
Auxiliary electricity consumption				Fan assisted heat output	NA
At nominal heat output	el_{max}	0,000	kW	Type of heat output/room temperature control (select one)	
At minimum heat output	el_{min}	0,000	kW	Single stage heat output an no room emperature control	No
In standby mode	el_{SB}	0,000	kW	Two or more manual stages, no room temperature control	No
				With mechanic thermostat room temperature control	Yes
				With electronic room temperature	No
				Electronic room temperature control plus day timer	No
				Electronic room temperature control plus week timer	No
				Other control options (multiple selections possible)	
				Room temperature control, with presence detection	No
				Room temperature control, with window detection	No
				With distance control option	No
				With adaptive start control	No
				With working time limitation	No
				With black bulb sensor	No



Information on Waste Disposal for Consumers of Electrical & Electronic Equipment

This mark on a product and/or accompanying documents indicates that when it is to be disposed of, it must be treated as Waste Electrical & Electronic Equipment (WEEE).

Any WEEE marked waste products must not be mixed with general household waste, but kept separate for the treatment, recovery and recycling of the materials used.

For proper treatment, recovery and recycling; please take all WEEE marked waste to your Local Authority Civic waste site, where it will be accepted free of charge.

If all consumers dispose of Waste Electrical & Electronic Equipment correctly, they will be helping to save valuable resources and preventing any potential negative effects upon human health and the environment, of any hazardous materials that the waste may contain.

Imported by
B&M Retail Ltd
The Vault, Dakota Drive,
Estuary Commerce Park,
Speke, Liverpool, L24 8RJ, UK
Centz Stores 7 Ltd, A94 K1H5, Ireland

Enjoy it.

Your statutory rights are not affected.

Made in China.

All brand names are registered trademarks of their respective owners.